

MILWAUKEE TOOL

13135 West Lisbon Road • Brookfield WI 53005 • 262-781-3600

To Whom It May Concern,

Milwaukee®, in partnership with Industrial Hygiene Sciences, LLC, has conducted testing on the Milwaukee M18[™] 2-Gallon Wet/Dry Vacuum (0880-20) paired with the M18[™] FUEL[™] 7" / 9" Large Angle Grinder (2785-20), 2" Diamond Dry Core Bit (48-17-0020), and SDS Max Dust Extraction Attachment (5317-DE). Results show that the user will be below the Permissible Exposure Limit (PEL) as described by OSHA 29 CFR 1926.1153 when using the above combination, assuming it is used in accordance with manufacturer's instructions. Testing results and procedures are outlined below:

Unit Tested	Average Cores Drilled	Average Sample Duration	% Silica (Quartz) in Sample	Average Respirable Crystalline Silica Concentration (µg/m³)	OSHA PEL in 1926.1153
	24	62	11.65	11.1 µg/m³ TWA	50 µg/m³

- All drilling was performed using a Milwaukee M18[™] 2-Gallon Wet/Dry Vacuum (0880-20) paired with the M18[™] FUEL[™] 7" / 9" Large Angle Grinder (2785-20), 2" Diamond Dry Core Bit (48-17-0020), and SDS Max Dust Extraction Attachment
- The drilling was completed horizontally to mounted concrete. The holes were drilled through each block and went all the way through both walls of the block.
- The HEPA filter was knocked out into a garbage can after every 4 cores drilled. The box was not emptied during the duration of the trial.
- A new HEPA filter and clean vacuum box were used for each trial.
- Work was performed in an enclosure with no outside ventilation. Th room was aired out with a fan after each trial.
- Samples were collected on 3 piece 37 mm diameter preweighed PVC filter mounted in a BGI GK2.69 respirable dust sampler, run at 4.2 lpm and connected to a GilAir Plus air sampling pump. The flow rate through the sampling train was measured using a TSI 4146 Calibrator before and after each Trial. A field blank was submitted with each day's set of samples.
- Samples were analyzed using OSHA ID-142 by the Wisconsin Occupational Health Laboratory, an AIHA Accredited laboratory. The sampling method used meets the definition of respirable crystalline silica in 1926.1153 (a) and Appendix A of the OSHA Respirable Crystalline Silica Standard (1926.1153).
- The Time Weighted Average (TWA) was calculated assuming zero exposure to respirable crystalline silica for the non-sampled portion of a 480 minutes (8 hour) shift. Longer exposure times, assuming that the dust exposures would be similar to those collected in these trials, would likely result in higher TWAs. Factors including, but not limited to, the ventilation and air flow patterns in the space where the work is done, how the tool is used, how sharp the bit is, the user's technique, the silica content of the cement block, how many cores are made, the presence of other respirable silica dust generating activities in the area, and vacuum maintenance could affect actual user exposure.

*A 2" Diamond Dry Core Bit reflects the dust generating application used in this test, the table below suggest other bit sizes based on volume of dust would also be compliant when using the Milwaukee M18[™] 2 Gallon Wet/Dry Vacuum.

Details on how to properly implement as a part of a complete exposure plan are outlined below*:

Hole Depth

	1"	1-1/4"	1-1/2"	1-3/4"	2"	2-1/2"
1"	1,145	875	708	595	513	402
1-1/2"	763	583	472	396	342	268
2"	572	437	354	297	256	201
2-1/2"	458	350	283	238	205	160
3"	381	291	236	198	171	134
3-1/2"	327	250	202	170	146	114
4''	286	218	177	148	128	100
4-1/2"	254	194	157	132	114	89
5"	229	175	141	119	102	80

Maximum Number of Holes per Day**

Hole Diameter

*These calculations are offered for reference and are calculated values based on previously recorded test data and represent a full workday of the tested application

** The user must drill the same number or fewer holes than those listed above for the given application in order to be considered compliant with the objective data clause of 29 CFR 1926.1153 OSHA regulation on crystalline silica dust.

It is the responsibility of the user to operate the tool in accordance with manufacturer's instructions. For the latest listings of approvals, visit milwaukeetool.com. For technical or service assistance, contact Milwaukee Customer Service at 1-800-729-3878.